



Código Focker	Nr. Original	Descricao	Interno	Externo	Alt.h	Alt.H
01344-RPU	D.0375.	RASPADOR	3/8	5/8		1/8
01345-RPU	D.0437.	RASPADOR	7/16	11/16		1/8
00632-RPU	D.0500	RASPADOR	1/2	3/4		1/8
00767-RPU	D.0562	RASPADOR	9/16	13/16		1/8
00684-RPU	D.0625	RASPADOR	5/8	7/8		1/8
01028-RPU	D.0687.	RASPADOR	11/16	15/16		1/8
00662-RPU	D.0750	RASPADOR	3/4	1" 1/8		3/16
01346-RPU	D.0812.	RASPADOR	13/16	1" 3/16		3/16
00527-RPU	D.0875	RASPADOR	7/8	1" 1/4		3/16
01347-RPU	D.0937.	RASPADOR	15/16	1" 5/16		3/16
00519-RPU	D.1000	RASPADOR	1"	1" 3/8		3/16
00592-RPU	D.1125	RASPADOR	1" 1/8	1" 1/2		3/16
00617-RPU	D.1187	RASPADOR	1" 3/16	1" 9/16		3/16
00512-RPU	D.1250	RASPADOR	1" 1/4	1" 5/8		3/16
00614-RPU	D.1375	RASPADOR	1" 3/8	1" 3/4		3/16
01350-RPU	D.1437.	RASPADOR	1" 7/16	1" 13/16		3/16
00501-RPU	D.1500.	RASPADOR	1" 1/2	1" 7/8		3/16
00618-RPU	D.1562	RASPADOR	1" 9/16	1" 15/16		3/16
00664-RPU	D.1625	RASPADOR	1" 5/8	2"		3/16
00548-RPU	D.1750	RASPADOR	1" 3/4	2" 1/8		3/16
00585-RPU	D.1875	RASPADOR	1" 7/8	2" 1/4		3/16
01353-RPU	D.1937.	RASPADOR	1" 15/16	2" 5/16		3/16
00550-RPU	D.2000	RASPADOR	2"	2" 1/2		1/4
01354-RPU	D.2062.	RASPADOR	2" 1/16	2" 9/16		1/4
00587-RPU	D.2125	RASPADOR	2" 1/8	2" 5/8		1/4
01355-RPU	D.2187.	RASPADOR	2" 3/16	2" 11/16		1/4
00534-RPU	D.2250	RASPADOR	2" 1/4	2" 3/4		1/4
00581-RPU	D.2375	RASPADOR	2" 3/8	2" 7/8		1/4
00549-RPU	D.2500	RASPADOR	2" 1/2	3"		1/4
01185-RPU	D.2562.	RASPADOR	2" 9/16	3" 1/16		1/4
00977-RPU	D.2625.	RASPADOR	2" 5/8	3" 1/8		1/4
00583-RPU	D.2750	RASPADOR	2" 3/4	3" 1/4		1/4
00983-RPU	D.2875.	RASPADOR	2" 7/8	3" 3/8		1/4
01360-RPU	D.2937.	RASPADOR	2" 15/16	3" 7/16		1/4
00551-RPU	D.3000.	RASPADOR	3"	3" 1/2		1/4
00597-RPU	D.3125	RASPADOR	3" 1/8	3" 5/8		1/4
00661-RPU	D.3250	RASPADOR	3" 1/4	3" 3/4		1/4
00735-RPU	D.3375	RASPADOR	3" 3/8	3" 7/8		1/4
00751-RPU	D.3500	RASPADOR	3" 1/2	4"		1/4
01361-RPU	D.3625.	RASPADOR	3" 5/8	4" 1/8		1/4
00760-RPU	D.3750	RASPADOR	3" 3/4	4" 1/4		1/4
00717-RPU	D.3875	RASPADOR	3" 7/8	4" 3/8		1/4
00660-RPU	D.4000	RASPADOR	4"	4" 1/2		1/4
01029-RPU	D.4250.	RASPADOR	4" 1/4	4" 3/4		1/4
00736-RPU	D.4375	RASPADOR	4" 3/8	4" 7/8		1/4
01117-RPU	D.4500.	RASPADOR	4" 1/2	5" 1/4		3/8
00798-RPU	D.4625	RASPADOR	4" 5/8	5" 3/8		3/8
01079-RPU	D.4750.	RASPADOR	4" 3/4	5" 1/2		3/8
00964-RPU	D.5000.	RASPADOR	5"	5" 3/4		3/8
00803-RPU	D.5125	RASPADOR	5" 1/8	5" 7/8		3/8
01296-RPU	D.5250.	RASPADOR	5" 1/4	6"		3/8
01365-RPU	D.5375.	RASPADOR	5" 3/8	6" 1/8		3/8
00806-RPU	D.5500	RASPADOR	5" 1/2	6" 1/4		3/8

RASPADOR POLEGADAS

00003

Código Focker	Nr. Original	Descricao	Interno	Externo	Alt.h	Alt.H
01065-RPU	D.6000.	RASPADOR	6"	6" 3/4		3/8
01369-RPU	D.6250.	RASPADOR	6" 1/4	7"		3/8
01277-RPU	D.6500.	RASPADOR	6" 1/2	7" 1/4		3/8
01253-RPU	D.6750.	RASPADOR	6" 3/4	7" 1/2		3/8
01135-RPU	D.7000.	RASPADOR	7"	7" 3/4		3/8
01276-RPU	D.7250.	RASPADOR	7" 1/4	8"		3/8
01108-RPU	D.7500.	RASPADOR	7" 1/2	8" 1/4		3/8
01370-RPU	D.7750	RASPADOR	7" 3/4	8" 1/2		3/8
01021-RPU	D.8000.	RASPADOR	8"	8" 3/4		3/8
01316-RPU	D.8125	RASPADOR	8" 1/8	8" 7/8		3/8
01242-RPU	D.8250.	RASPADOR	8" 1/4	9"		3/8
01371-RPU	D.8500.	RASPADOR	8" 1/2	9" 1/4		3/8
01373-RPU	D.9000	RASPADOR	9"	9" 3/4		3/8